



Einhell



EXPERT

Cordless Lawn Trimmer

GE-CT 18/30 Li-Solo

Item No.: 3411250

Ident No.: 21010

Bar Code: 4006825659399

The Einhell GE-CT 18/30 Li Solo cordless grass trimmer presents you with the perfect lawn. While the telescopic long handle is easy, quick and convenient to extend or shorten, the additional handle and Softgrip provide for perfect comfort. The motor head can be rotated through 90° for cutting vertical surfaces and lawn edges. Together with the guide wheel the chances of cutting edges with high precision could not be better. There are 3 tilt settings for flexible operation. A flower guard protects plants and trees from damage. Delivery includes a line spool (5m) with automatic jog line feed for practical feeding. You need one 18 V battery from the PXC series to operate the grass trimmer. This product comes without a battery or charger.

Features & Benefits


- Member of the Power X-Change family, 1x18V battery necessary
- Easy, fast & convenient telescoping of the long handle.
- Adjustable additional handle - comfortable handling
- Motor head rotatable 90° for vertical surfaces / lawn edges
- Incl. edging-wheel - enables precise edge trimming
- Motor head tiltable at 3 settings - versatile working
- Flower guard - protecting flowers and trees against damage
- Incl. line spool (5m) with bump-feed system
- Softgrip - perfect comfort
- Supplied without battery and charger (available separately)

Technical Data

- Cutting feature	Single line
- Revolutions of thread	8500 rpm
- Thread diameter	1.6 mm
- Cutting width of thread	300 mm
- Thread length	500 cm
- Readjustment of thread	Tip automatic

Logistic Data

- Product weight	2.1 kg
- Gross weight single packaging	2.8 kg
- Dimensions single packaging	225 x 138 x 970 mm
- Pieces per export carton	4 Pieces
- Gross weight export carton	12.5 kg
- Dimensions export carton	990 x 465 x 295 mm



Available as special accessories



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



2x 5,2Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



18V 3,0 Ah Power-X-Change
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 2
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 4,0Ah Power X-Change 2
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



2x 3,0Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512083
Bar Code: 4006825638509
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack CB
Battery
Item No.: 4511524
Bar Code: 4006825656206
Einhell Accessory



5,2Ah & 4A Fastcharger
PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory



18V 4,0Ah PXC Starter Kit 2
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 4,0Ah Power-X-Change Plus
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



2x 4,0Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory

Battery-Running-Times



trimming¹
(min.)

One Battery for All

1.5 Ah

2.0 Ah

2.5 Ah

3.0 Ah

4.0 Ah

5.2 Ah

6.0 Ah

Test setup:

1) -